



# Occupancy Sensor Instructions

Ceiling Mount (MC-C)	Wall Mount (MC-W)
 3.3" diameter x 2.2" deep Extends about 5/8" from ceiling	 3.3" x 3.3" x 2.1" deep Mounting bracket adds additional depth (see below)

## Operation


These 24V occupancy sensors automatically turn on your Energy Recovery Ventilator (ERV) when they detect the difference between infrared energy from a human body in motion and the background space. After the area is vacated and the (adjustable) time delay elapses, the ERV automatically turns off.

## Installation

Ceiling Mount	Wall Mount
	


## CONNECTION DIAGRAMS: EV70, EV130, EV200 and EV300 models

MC-C Ceiling Mount Control connected to RenewAire EV-series ERV (separate source of 24VAC power required)



This schematic applies to EV70, EV130, EV200 & EV300 models only.

MC-W Wall Mount Control connected to RenewAire EV-series ERV (separate source of 24VAC power required)




This schematic applies to EV70, EV130, EV200 & EV300 models only.

## CONNECTION DIAGRAMS:


### All EV450 models and HE1XIN starting January 2011

**MC-C Ceiling Mount Control connected to RenewAire HE-series commercial ERV with on-board 24VAC power (Pigtail connections).**



This schematic applies to all EV450 models, and to HE1XIN models.

**MC-W Wall Mount Control connected to RenewAire HE-series commercial ERV with on-board 24VAC power (Pigtail connections).**




This schematic applies to all EV450 models, and to HE1XIN models.

## CONNECTION DIAGRAMS:


### HE1XRT models, and all HE2X through HE8X models starting January 2011

**MC-C Ceiling Mount Control connected to RenewAire HE-series commercial ERV with on-board 24VAC power (Terminal strip connections).**



This schematic applies to HE1XRT models, and to all HE2X through HE8X models.

**MC-W Wall Mount Control connected to RenewAire HE-series commercial ERV with on-board 24VAC power (Terminal strip connections).**



This schematic applies to HE1XRT models, and to all HE2X through HE8X models.


## Sensor Adjustment (Time Delays/ Sensitivity/ Override)

### Ceiling Mount MC-C

All sensor adjustments are set with DIP Switches #1 thru #4.

DIP Switch #	1	2	3	4
<b>Time Delays</b>				
30 seconds	●	●		
10 minutes	●	-		
20 minutes	-	●		
30 minutes	-	-		
<b>Sensitivity</b>				
Minimum		-		
Maximum		●		
<b>Override</b>				
Normal		-		
Override		●		

● = ON   - = OFF   ← = factory presets



DIP Switch #	1	2	3	4	5
15 seconds	●	●	●	●	-
2 minutes	-	-	●	●	-
4 minutes	●	-	●	●	-
6 minutes	-	-	●	●	-
8 minutes	●	●	-	●	-
10 minutes	-	●	-	●	-
12 minutes	●	-	-	●	-
14 minutes	-	-	-	●	-
16 minutes	●	●	-	-	-
18 minutes	-	●	●	-	-
20 minutes	●	-	●	-	-
22 minutes	-	-	●	-	-
24 minutes	●	●	-	-	-
26 minutes	-	●	-	-	-
28 minutes	●	-	-	-	-
30 minutes	-	-	-	-	-
Override	-	-	-	-	●

● = on   - = off   ← = factory preset

